





PV+ PV-



LAN RS232

BAT(+) BAT(-)



BAT TEMP



+ LOAD -











The interface of upper computer software working state



The interface of upper computer software parameter setting state



Upper computer software on/off interface and generating capacity record clean interface



The interface of test software working state

MPPT□□□





