Introduction

This e-SMART MPPT (maximum Power Point Tracking) solar charge controller is a smart solar controller with automatic recognition function, smart charging and discharging function, three stages charging function to protect battery. It can increase 30%~60% efficiency than traditional PWM controller. It supports many kinds of batteries. It also have RS232 communication function.



Remarks:DC12V/24V/48V battery system automatic recognised.

Features

1. MPPT charging mode, peak efficiency up to 99%, saving 30%~60% solar panel than traditional PWM controller.

2. DC12V/24V/48V battery system automatic recognition, users can use it in different system conveniently.

3. Maximum PV input voltage up to DC100V.

4. Three stages charge: fast charge(MPPT), constant voltage charge,floating charge, It can protect batteries well .

5. Three option of discharge: on mode and off mode and PV voltage(solar) control mode.

6. Users can choose 4 kinds of commonly standard batteries(Sealed lead acid, Vented, Gel, NiCd). Other kinds of batteries can be defined by users.

7. Digital tube can display battery voltage and charging current. The software can display various parameters such as model number, PV input voltage, battery type, battery voltage, charging current, charging power, working condition.

8. RS232 communication, we can offer communication protocol also, it's convenient for user's integration management.

- 9. This controller can be paralleled infinitely.10. CE and RoHS Certifications are approved. We can help clients to approve other certifications.
- 11. 2 years warranty; 3~10 years extended technical service.

Parameters

MPPT solar controlle I-P-e-SMART-12V/24		15A	20A	25A	30A	40A
		MPPT(maximum power point tracking)				
Charge method	Three stages: constant current(MPPT),constant voltage,floating charge					
System type	-	Automatic re		voitage, iit		
	12V system	DC9V~DC15V				
System voltage	24V system	DC3V~DC13(DC18V~DC3(
	48V system	DC18V~DC30 DC36V~DC60				
Soft start time	12V/24V/48V system					
Dynamic response	12 V/24 V/40 V System					
recovery time	12V/24V/48V system					
MPPT efficiency	12V/24V/48V system	≥96.5%,≤99	%			
INPUT CHARACTERIS	-	i				
MPPT working	12V system	DC14V~DC10				
voltage range	24V system	DC30~DC100				
	48V system	DC60~DC100)V			
Low input voltage	12V system	DC14V				
protection point	24V system	DC30V				
	48V system	DC60V				
Low input voltage	12V system	DC18V				
Recovery point	24V system	DC34V				
	48V system	DC65V				
High input voltage protection point	12V/24V/48V system	DC110				
High input voltage recovery point	12V/24V/48V system	DC100V				
Maximum PV power	12V system (W)	213	284	355	426	568
		426	568	710	852	1136
		852	1136	1420	1704	2272
CHARGE CHRECTRE					4	
pattery)	12V/24V/48V System		of the batterie	es also ca	n be defined)	
Constant Voltage	12V/24V/48V system	Planca chack	the charge w		ording to the	hattony tuna
Floating Charge Voltage	12V/24V/48V system	Please check the charge voltage according to the battery type form.				battery type
	12V/24V/48V system	154	20A	25A	30A	40A
Current-limit	-					
Protection	12V/24V/48V system	20A	25A	30A	35A	45A
Temperature Factor	12V/24V/48V system	±0.02%/°C				
Temperature Compensation	12V/24V/48V system	14.2V-(The hi	ghest temper	ature-25°	C)*0.3	
Output Ripples(peak)	12V/24V/48V system	200mV				

Output Voltage				
Stability	12V/24V/48V system	<+1.5%		
Precision				
Output Discharge C	haracteristics			
_		Base on battery voltage		
Protection point		Default 10.5V; Recovery 11V; It can be adjustable.		
		30A		
The output control		On mode, Off mode, PV voltage control mode		
Output control set n	node	Controller button or PC software		
Display				
		Battery voltage, Charge current		
		Charging indicator light, LOAD indicator light		
PC ₋ communication	port[]	RS232		
Protection				
Low input voltage p		Check the input characteristics		
High input voltage p	protection	Check the input characteristics		
Charge overpower p		yes		
Discharge low volta		yes		
Discharge high curr	ent protection	yes		
Temperature protect	tion	yes		
Other Parameters				
Noise		≤40dB		
Thermal heat-dissip	ating method	Itself cooling Fan cooling		
Components		Imported material With EU standards.		
Certification		CE\FCC\RoHS		
Physical				
Measurement D x W x H(mm)		205*168*60		
package size D x W x H(mm)		265*196*110		
N.G(KG)		1.8kg		
G.N(KG)		2kg		
Mechanical Protection		IP25		
Environment				
Humidity		0~90%RH (no condense)		
Altitude		0~3000m		
Operating Temperature		-20°C ~ +50°C		
Storage Temperatur		-40°C ~ +75°C		
Atmospheric Pressu	re	70~106kPa		

Remarks

The specification is only for reference. Subject to change without prior notice

We provide OEM and ODM service. The 36V/72V/96V model also can be customized for you.

Products Package

Number	quantity	Items included
1		Controller color (blue or green is optional OEM ODM order is highly welcome)
2	2 рс	Hangers (used for controller hanging on the wall)
3	4 set	Screw
4	1 pc	RJ45 to RS232 cable

5	1 pc	Battery temperature sensor wire	
6	2 pc	Fuse[]DC output[]	
7	1 pc	User instruction[]manual[]	
8	1 pc	CD	

1.Controller PC upper software and testing software can display information. Users can set parameters via PC upper software.

 See and a second	10000	
	The CH - Annual CH V	Jahn
	14 Martin	MAMAAA

Graphical: PC upper software

Graphical: testing software

1.1 The first picture show solar controller working status(charge and discharge), PV voltage, charge voltage, charge current etc. Users can choose the type of the batteries, DC-load output control method.1.2 We provide PC upper software. Testing software is not including. (user's PC has software development platform, if needed, please apply for it)

2. Information display and parameter setting.



Figure 2.1

Figure 2.2

2.1 ENTER1 button: press left ENTER1 show 2 digital battery voltage[]if it is charging, then shows 2 digital charge voltage), for example, the battery voltage or charge voltage is 13.5V, it shows13, please see Figure 2.1; Press ENTER1 a little bit longer, users can set battery types.

2.2 ENTER2 button: press right ENTER2 show 2 digital battery current (if it is not charging, then it display 00, if the charge current is 22.5A, then it shows 22,please see Figure 2.2); press ENTER2 button a little bit

longer, DC load control can be set (On mode, Off mode, PV voltage control mode) Please see more details in the user manual.

Other detailed parameters

Please see the outline of the design, technical documents, user manuals etc. Research and development department made 2th version on May 5, 2014.