Introduction

This e-SMART MPPT (maximum Power Point Tracking) solar charge controller is a smart solar controller with automatic recognition function, smart charging and discharging function, three stages charging function to protect battery. It can increase 30%~60% efficiency than traditional PWM controller. It supports many kinds of batteries. It also have RS232 communication function.

Features

- 1. MPPT charging mode, peak efficiency up to 99%, saving 30%~60% solar panel than traditional PWM controller.
- 2. DC12V/24V/48V battery system automatic recognition, users can use it in different system conveniently.
- 3. Maximum PV input voltage up to DC100V.
- 4. Three stages charge: fast charge(MPPT), constant voltage charge, floating charge, It can protect batteries well .
- 5. Three option of discharge: on mode and off mode and PV voltage(solar) control mode.
- 6. Users can choose 4 kinds of commonly standard batteries(Sealed lead acid, Vented, Gel, NiCd). Other kinds of batteries can be defined by users.
- 7. Digital tube can display battery voltage and charging current. The software can display various parameters such as model number, PV input voltage, battery type, battery voltage, charging current, charging power, working condition.
- 8. RS232 communication, we can offer communication protocol also, it's convenient for user's integration management.
- 9. This controller can be paralleled infinitely.
- 10. CE and RoHS Certifications are approved. We can help clients to approve other certifications.
- 11. 2 years warranty; 3~10 years extended technical service.

Parameters

MPPT solar controller modes I-P-e-SMART-12V/24V/48V-series		15A	20A	25A	30A	40A	
Charge mode	rge mode MPPT(maximum power point tracking)						
Charge method	Three stages: constant current(MPPT),constant voltage,floating charge						
System type	DC12V/24V/48V	Automatic recognition					
System voltage	12V system	DC9V~DC15V					
	24V system	DC18V~DC30V					
	48V system	DC36V~DC60V					
Soft start time	12V/24V/48V system	≤3S					
Dynamic response recovery time	12V/24V/48V system	500us					
MPPT efficiency	12V/24V/48V system	≥96.5%,≤99	%				
INPUT CHARACTERIS	INPUT CHARACTERISTICS						
MPPT working voltage range	12V system	DC14V~DC100V					
	24V system	DC30~DC100V					
	48V system	DC60~DC100V					
Low input voltage protection point	12V system	DC14V					
	24V system	DC30V					
	48V system	DC60V					
Low input voltage Recovery point	12V system	DC18V					
	24V system	DC34V					
	48V system	DC65V					

	T	1					
High input voltage protection point	12V/24V/48V system	DC110					
High input voltage recovery point	12V/24V/48V system	nDC100V					
реше	12V system (W)	213	284	355	426	568	
Maximum PV power		426	568	710	852	1136	
		852	1136	1420	1704	2272	
CHARGE CHRECTRE		032	11130	1120	12701	2272	
Selectable Battery	1						
Types (Default Gel battery)	12V/24V/48V system	(Other types of the batteries also can be defined)[
Constant Voltage	12V/24V/48V system	Please che	ck the char	ge voltage a	ccording to	the hattery type	
, ,	12V/24V/48V system	Please check the charge voltage according to the battery type form.				the battery type	
Voltage	12V/24V/48V system	15Λ	20A	25A	30A	40A	
Current-limit	12 V/24 V/40 V System	IJA	ZUA	ZSA	JUA	40A	
Protection	12V/24V/48V system		25A	30A	35A	45A	
	12V/24V/48V system	±0.02%/°C					
Temperature	 12V/24V/48V system	 14 2\/ ₋ (The	highest te	mnerature ₋ 2	5°C*∩ 3		
Compensation	12 V/2 + V/ + O V 3 y 3 t C i i i	14.2 V-(111C	. mgnest tei	inperature-2.	J C/ 0.J		
Output	12V/24V/48V system	200mV					
Ripples(peak)	12 V/2 + V/ + O V 3 y 3 t C i i i	2001111					
Output Voltage Stability	 12V/24V/48V system	≤±1.5%					
Precision							
Output Discharge Cl	naracteristics						
Output voltage		Base on battery voltage					
Low voltage output		Default 10.5V; Recovery 11V; It can be adjustable.					
Protection point							
Rated output Current		30A					
The output control		On mode, Off mode, PV voltage control mode					
Output control set m	node	Controller button or PC software					
Display							
LED digital tube display		Battery voltage, Charge current					
LED light display		Charging indicator light, LOAD indicator light					
PC communication port		RS232					
Protection							
Low input voltage p		Check the input characteristics					
High input voltage p		Check the input characteristics					
Charge overpower protection		yes					
Discharge low voltage	yes						
Discharge high curre	yes						
Temperature protec	yes						
Other Parameters							
Noise	≤40dB						
Thermal heat-dissipating method		Itself cooling Fan cooling					
Components		Imported material With EU standards.					
Certification CE\FC			HS				
Physical Depth Control Depth C							
Measurement D x W		205*168*60					
package size D x W x H(mm)		265*196*110					
N.G(KG)		1.8kg					
G.N(KG)		2kg					
Mechanical Protection		IP25					

Environment	
Humidity	0~90%RH (no condense)
Altitude	0~3000m
Operating Temperature	-20°C ~ +50°C
Storage Temperature	-40°C ~ +75°C
Atmospheric Pressure	70~106kPa

Products Package

Number	quantity	Items included
1	1 pc	Controller color (blue or green is optional OEM ODM order is highly welcome)
2	2 pc	Hangers (used for controller hanging on the wall)
3	4 set	Screw
4	1 pc	RJ45 to RS232 cable
5	1 pc	Battery temperature sensor wire
6	2 pc	Fuse[]DC output[]
7	1 pc	User instruction[manual]
8	1 pc	CD












Controller PC upper software and testing software

- 1. The first picture show solar controller working status(charge and discharge), PV voltage, charge voltage, charge current etc. Users can choose the type of the batteries, DC-load output control method.
- 2. We provide <u>PC upper software</u>. Testing software is not including. (user's PC has software development platform, if needed, please apply for it)





Information display and parameter setting

- 1. ENTER1 button: press left ENTER1 show 2 digital battery voltage if it is charging, then shows 2 digital charge voltage), for example, the battery voltage or charge voltage is 13.5V, it shows13, please see Figure 2.1; Press ENTER1 a little bit longer, users can set battery types.
- 2. ENTER2 button: press right ENTER2 show 2 digital battery current (if it is not charging, then it display 00, if the charge current is 22.5A, then it shows 22,please see Figure 2.2); press ENTER2 button a little bit longer, DC load control can be set (On mode, Off mode, PV voltage control mode) Please see more details in the user manual.





Applications



