### Introduction

<u>I-Panda</u> Pure sine wave inverter with built-in MPPT controller <u>I-P-HPC-Series</u> is a module design. It has the advantages of high conversion efficiency, low power consumption and strong load-carrying ability. With intelligent control, users can set charging mode, (Utility as complementary power) AC first mode or DC first mode, timing inversion mode and timing utility mode, on/off mode. <u>It is one of advanced hybrid inverter & controller in the world.</u>

# I-P-HPC-Series System



I-P-HPC-Series Inverter+Solar Controller





# **Application**

- 1.Off-grid solar power system
- 2. Solar and utility complementary power system



#### **Feature**

- 1.Easy to install.To configure a solar system, users just need to connect it with solar panels and batteries
- 2.CPU management, intelligent control, modular design, LCD display
- 3.Built-in MPPT controller, high charging efficiency
- 4.Low power consumption, high conversion efficiency
- 5.Intellectual multi-function, it's convenient for users to make full use of solar energy in different situation
- 6. External battery connection, it's convenient for users to expand back-up power time
- 7.Strong load-carrying ability, low failure rate, easy to maintenance and long service life (under proper operation, it can last at least 5 years)
- 8.Perfect protection:low voltage protection, high voltage protection, over temperature protection, short-circuit protection, overload protection
- 9.CE / EMC / LVD/ RoHS Approvals
- 10.Two years warranty, life-long technical support

## **Data sheet**

Parameter Model			1000W	1500W		2000W	3000W	4000W	5000W		
Rated Output Power			1000W	1500W		2000W	3000W	4000W	5000W		
Peak Power			2000W	3000W		4000W	6000W	8000W	1000W		
Battery							100000		1000044		
(Lead-acid battery[]			24V	24V/48V(optional)				48V			
Charging Paramete			1					1			
Charge Mode[setting[			PV charge								
			PV charge + utility charge								
	Voltage		24V 24V/48V					48V			
MPPT Solar Controller	Current		20A	25A		30A	40A	40A	40A		
	Max PV Input Voltage		100V								
	PV Charge Efficiency		95%~99%								
	Max PV Input Power		568W	24V: 710W		24V: 852W	24V:1136 W	-2272W	2272W		
				48V1420W		48V: 1704W	48V: 2272W		227200		
Utility	AC Charge Current		0~15A								
Charge Mode			3-Stage Charging								
Inversion paramet	er										
AC Output	Voltage	or 110V±3%	220V±3% or 230V±3 or 240V±3% or 100V±3% or 110V±3% (optional)								
	Frequency	50Hz±0.5 or 60Hz±0.5 (optional)									
		wave output, Total Harmonic Distortion THD≤3									
Overload ability >120% 1 mir		n, >130% 10s									
Power Consumption		0.4A		24V: 0.5A	24V:		: 0.7A	0.6A	0.65A		
(under normal working mode)				48V: 0.4A	48V:	0.45A 48V	: 0.5A	0.071	5.557.		
(under sleep mode)		1-6W	1-6W								
Inverter Conversion Efficiency 85%~92%		-92%									
Utility Mode				<u> </u>							
AC Input	Voltage		r 110V+35%[]optional[]								
	Frequency	The same as utility's frequency									
AC Output	Voltage	220V±5% or 110V+5%[optional]									
	Frequency	The same as utility's frequency									
		nin,>130% 10s									
(AC first or DC first	:) priority										
			AC first, DC standby								
		DC first, AC standby									

Switch Time		<5ms []AC to DC / [	≤5ms [AC to DC / DC to AC]								
Power On		Set by users	Set by users								
[setting[]		Timed on / off AC or	Timed on / off AC output automatically								
General Paramete	er										
Display	Display Mode	LCD+LED									
	Display Information	Input voltage, output voltage, output frequency, battery capacity, load condition, status Information									
Protection		Overload, short-circ	Overload, short-circuit, high-voltage input, low-voltage input, overheat								
Environment	Temperature	-10°C∏50°C									
	humidity	10%[]90%									
	Altitude	≤4000m									
Size W×D×H(mm)		438*208*413			450*246*468	450*246*468					
Packing Size W×D×H(mm)		520*310*460			540*300*518	540*300*518					
Net Weight (kg)		15	17	19	25	34	35				
Gross Weight (kg)		16	18	20	27	40	41	The state of the s			

#### **Function**

- 1. Charging function
- 1.1 PV only mode: when PV and utility are both connected to the inverter, only the PV will charge the battery while utility will not charge the battery.
- 1.2 PV+AC hybrid mode: when PV and utility are both connected to the inverter, both PV and utility will charge the battery.
- 2. Utility as complementary power UPS function
- 2.1AC first, DC standby UPS mode

When utility and battery are connected to the inverter, utility will supply power to the loads preferentially. When utility is cut off, the battery will automatically continue to supply power to the loads.

### Steps are as follows:

- Step 1: When utility power is available, it will drive the loads directly after voltage being stabilized and charge batteries at the same time.
- Step 2: When utility power is cut off suddenly, the inverter will convert DC to AC automatically to ensure uninterrupted power supply within 5ms.
- Step 3: When utility power is available again, it will automatically transfer to utility supplying power to loads and charge batteries at the same time.
- 2.2DC first, AC standby UPS mode:

When utility and battery are connected to the inverter, battery will supply power to the loads prior to utility. When battery capacity is not enough, utility will continue to supply power automatically.

#### Steps are as follows:

- Step 1: When battery has enough power, it will drive the loads directly via power inverter
- Step 2: When battery does not have enough power, it will automatically transfer to utility supplying power to the loads
- Step 3: After the battery is fully charged (e.g. by solar or wind charge controller), it will automatically transfer to battery supplying power to the loads.
- 3.Timing function
- 3.1 On/Off mode: Users can set specific time to turn on/off the output of the inverter.
- 3.2 Working mode: Battery or utility switchable mode. Users can set specific time when to use battery or utility supplying power (suitable for areas where electric fee is charged differently in different period)
- 4.Recording/checking function
- 4.1 Inverter fault checking: Users can check the inverter fault information
- 4.2 Discharge time checking: Users can check the discharge time of the battery

# LDC display



