### The Connection diagram:



### Features:

1. MPPT charging mode, peak efficiency up to 99%, saving 30%~60% solar panel than traditional PWM controller.

2. DC12V/24V/48V battery system automatic recognition, users can use it in different system conveniently.

3. Maximum PV input voltage up to DC100V.

4. Three stages charge: fast charge(MPPT), constant voltage charge,floating charge, It can protect batteries well .

5. Three option of discharge: on mode and off mode and PV voltage(solar) control mode.

6. Users can choose 4 kinds of commonly standard batteries(Sealed lead acid, Vented, Gel, NiCd). Other kinds of batteries can be defined by users.

7. Digital tube can display battery voltage and charging current. The software can display various parameters such as model number, PV input voltage, battery type, battery voltage, charging current, charging power, working condition.

8. RS232 communication, we can offer communication protocol also, it's convenient for user's integration management.

9. This controller can be paralleled infinitely.

- 10. CE and RoHS Certifications are approved. We can help clients to approve other certifications.
- 11. 2 years warranty;  $3\sim10$  years extended technical service.

## **Parameters:**

MPPT solar contr I-P-e-SMART-12V		25A
Charge mode	ן MPPT(maximum	power point tracking)
Charge method	Three stages: con charge	stant current(MPPT),constant voltage,floating
System type	DC12V/24V/48V	Automatic recognition
	12V system	DC9V~DC15V
System voltage	24V system	DC18V~DC30V
	48V system	DC36V~DC60V
Soft start time	12V/24V/48V system	≤3S
Dynamic response recovery time	12V/24V/48V system	500us
	12V/24V/48V system	≥96.5%,≤99%
INPUT CHARACT	ERISTICS	
MPPT working	12V system	DC14V~DC100V
voltage range	24V system	DC30~DC100V
voltage range	48V system	DC60~DC100V
Low input	12V system	DC14V
voltage	24V system	DC30V
protection point	48V system	DC60V
Low input	12V system	DC18V
voltage	24V system	DC34V
Recovery point	48V system	DC65V
High input voltage protection point	12V/24V/48V system	DC110
High input voltage recovery point	12V/24V/48V system	DC100V
Movimum DV	12V system (W)	355
Maximum PV	24V system (W)	710
power	48V system (W)	1420
CHARGE CHREC	TRESTICS	
Selectable Battery Types (Default Gel battery)	12V/24V/48V system	Sealed lead acid, Vented, Gel, NiCd battery (Other types of the batteries also can be defined)[]

	1 23 7/2 43 7/4 03 7		
Constant Voltage	12V/24V/48V		
	system	Please check the charge voltage according to the	
Floating Charge	12V/24V/48V	battery type form.	
Voltage	system		
Rated Input	12V/24V/48V	25A	
Current	system		
Current-limit	12V/24V/48V	30A	
Protection	system		
Temperature	12V/24V/48V	±0.02%/°C	
Factor	system	±0.02%/C	
Temperature	12V/24V/48V	14 DV (The high est temperature 25%)*0.2	
Compensation	system	14.2V-(The highest temperature-25°C)*0.3	
Output	12V/24V/48V	200-17	
Ripples(peak)	system	200mV	
Output Voltage			
Stability	12V/24V/48V	≤±1.5%	
Precision	system		
Output Discharge	Characteristics		
Output voltage		Base on battery voltage	
1 0			
Low voltage outp	ut	Default 10.5V; Recovery 11V; It can be adjustable.	
Protection point			
Rated output Cur		30A	
The output control		On mode, Off mode, PV voltage control mode	
Output control se	et mode	Controller button or PC software	
Display			
LED digital tube	display	Battery voltage, Charge current	
LED light display	,	Charging indicator light, LOAD indicator light	
PC <sub>C</sub> communicati	on port[]	RS232	
Protection			
Low input voltage	e protection	Check the input characteristics	
High input voltage protection		Check the input characteristics	
Charge overpower protection		ves	
Discharge low vo		ves	
<u>v</u>	urrent protection	yes	
Temperature protection		yes	
Other Parameter		<u> </u>	
Noise	0	≤40dB	
Thermal heat-dissipating method		Itself cooling Fan cooling	
Components	sipating method	Imported material With EU standards.	
Certification		*	
		CE\FCC\RoHS	
Physical New York Date	- TAT TT( )		
Measurement D x		205*168*60	
package size D x	vv x H(mm)	265*196*110	
N.G(KG)		1.8kg	
G.N(KG)		2kg	
Mechanical Prote	ection	IP25	
Environment			
Humidity		0~90%RH ( no condense)	
Altitude		0~3000m	
Operating Tempe	erature	-20°C ~ +50°C	
Storage Tempera		-40°C ~ +75°C	
Atmospheric Pres		70~106kPa	
·*			

#### Remarks[]

- 1. The specification is only for reference. Subject to change without prior notice
- 2. We provide OEM and ODM service. The 36V/72V/96V model also can be customized for you.

# **Products Package**


Number	quantity	ltems included
1	1 pc	Controller color (blue or green is optional OEM ODM order is highly welcome )
2	2 pc	Hangers (used for controller hanging on the wall)
3	4 set	Screw
4	1 pc	RJ45 to RS232 cable
5	1 pc	Battery temperature sensor wire
6	2 pc	Fuse[]DC output[]
7	1 pc	User instruction[]manual[]
8	1 pc	CD

Controller PC upper software and testing software

1. Controller PC upper software and testing software can display information. Users can set parameters via PC upper software.

Bhh W Ame	Terms (191) - manufacture (191)
Y NEW Y	
-tarboxisti - Baran -	
They downed	the test series
marine 1111 Paris 1114	
The set 1 is a line of the	
And the second s	

Graphical: PC upper software



Graphical: testing software

1.1 The first picture show solar controller working status(charge and discharge), PV voltage, charge voltage, charge current etc. Users can choose the type of the batteries, DC-load output control method.

1.2 We provide PC upper software. Testing software is not including. (user's PC has software development platform, if needed, please apply for it)

2. Information display and parameter setting.



Figure 2.1





2.1 ENTER1 button: press left ENTER1 show 2 digital battery voltage [] if it is charging, then shows 2 digital charge voltage), for example, the battery voltage or charge voltage is 13.5V, it shows13, please see Figure 2.1; Press ENTER1 a little bit longer, users can set battery types.

2.2 ENTER2 button: press right ENTER2 show 2 digital battery current (if it is not charging, then it display 00, if the charge current is 22.5A, then it shows 22,please see Figure 2.2); press ENTER2 button a little bit longer, DC load control can be set (On mode, Off mode, PV voltage control mode)

Please see more details in the user manual.

# **Other detailed parameters**

Please see the outline of the design, technical documents, user manuals etc. Research and development department made 2th version on May 5, 2014.