Product Description

This e-SMART_MPPT_solar charge controller (maximum Power Point Tracking) is a smart solar controller with automatic recognition function, smart charging and discharging function, three stages charging function to protect battery. It can increase 30%~60% efficiency than traditional PWM controller. It supports many kinds of batteries. It also have RS232 communication function.



Remarks:DC12V/24V/48V battery system automatic recognised.

Features

- 1. MPPT charging mode, peak efficiency up to 99%, <u>saving 30%~60% solar panel</u> than traditional PWM controller.
- 2. DC12V/24V/48V battery system automatic recognition, users can use it in different system conveniently.
- 3. Maximum PV input voltage up to DC100V.
- 4. Three stages charge: fast charge(MPPT), constant voltage charge, floating charge, It can protect batteries well .

- 5. Three option of discharge: on mode and off mode and PV voltage(solar) control mode.
- 6. Users can choose 4 kinds of commonly standard batteries(Sealed lead acid, Vented, Gel, NiCd). Other kinds of batteries can be defined by users.
- 7. Digital tube can display battery voltage and charging current. The software can display various parameters such as model number, PV input voltage, battery type, battery voltage, charging current, charging power, working condition.
- 8. RS232 communication, we can offer communication protocol also, it's convenient for user's integration management.
- 9. This controller can be paralleled infinitely.
- 10. <u>CE and RoHS Certifications</u> are approved. We can help clients to approve other certifications.
- 11. 2 years warranty; 3~10 years extended technical service.

Data sheet

MPPT solar controller modes□ I-P-e-SMART-12V/24V/48V-series		15A	20A	25A	30A	40A	
	MPPT(maximum power point tracking)						
Charge method	Three stages: constant current(MPPT),constant voltage,floating charge						
System type	DC12V/24V/48V Automatic recognition						
System voltage		DC9V~DC15V					
	24V system	DC18V~DC30V					
	48V system	DC36V~DC60V					
Soft start time	12V/24V/48V system	≤ 3S					
Dynamic response recovery time	12V/24V/48V system						
MPPT efficiency	12V/24V/48V system	≥96.5%,≤99	%				
INPUT CHARACTERIS	TICS						
MDDT working	12V system	em DC14V~DC100V					
MPPT working voltage range	24V system	DC30~DC100V					
	48V system	DC60~DC100	DC60~DC100V				
Low input voltage	12V system	DC14V					
protection point	24V system	DC30V					
protection point	48V system	DC60V					
Low input voltage	12V system	DC18V					
Low input voltage Recovery point	24V system	DC34V					
	48V system	DC65V	DC65V				
High input voltage protection point	12V/24V/48V system	V/24V/48V system DC110					
High input voltage recovery point	12V/24V/48V system	DC100V					
	12V system (W)	213	284	355	426	568	
Maximum PV power	24V system (W)	426	568	710	852	1136	
·	48V system (W)	852	1136	1420	1704	2272	
CHARGE CHRECTRES	STICS						
pattery)	12V/24V/48V System	Sealed lead acid, Vented, Gel, NiCd battery (Other types of the batteries also can be defined)□					
	12V/24V/48V system	Diogga alaasis				battam turi	
Floating Charge Voltage	12V/24V/48V system	Please check the charge voltage according to the battery type form.					
	12V/24V/48V system	15A	20A	25A	30A	40A	
Current limit	12V/24V/48V system		25A	30A		45A	

Temperature Factor	12V/24V/48V system	±0.02%/°C				
Temperature	•		2E°C)*0 2			
Compensation	12V/24V/48V System	14.2V-(The highest temperature-25°C)*0.3				
Output	12V/24V/48V system	200mV				
Ripples(peak)	12 V/24 V/40 V System					
Output Voltage						
	12V/24V/48V system	≤±1.5%				
Precision						
	Output Discharge Characteristics					
		Base on battery voltage				
Low voltage output		Default 10.5V; Recovery 11V; It can be adjustable.				
Protection point						
I		30A				
The output control		On mode, Off mode, PV voltage control mode				
Output control set m	node	Controller button or PC software				
Display						
LED digital tube disp	olay	Battery voltage, Charge current				
LED light display		Charging indicator light, LOAD indicator light				
PC communication	oort[]	RS232				
Protection						
Low input voltage protection		Check the input characteristics				
High input voltage protection		Check the input characteristics				
Charge overpower protection		yes				
Discharge low voltage protection		yes				
Discharge high current protection		yes				
Temperature protect	tion	yes				
Other Parameters						
Noise		≤40dB				
Thermal heat-dissipating method		Itself cooling	Fan cooling			
Components		Imported material With EU standards.				
Certification		CE\FCC\RoHS				
Physical						
Measurement D x W x H(mm)		205*168*60				
package size D x W x H(mm)		265*196*110				
N.G(KG)		1.8kg				
G.N(KG)		2kg				
Mechanical Protection		IP25				
Environment						
		0~90%RH (no condense)				
Altitude		0~3000m				
Operating Temperature		-20°C ~ +50°C				
Storage Temperature		-40°C ~ +75°C				
Atmospheric Pressur	re	70~106kPa				

☐ Remarks

The specification is only for reference. Subject to change without prior notice

We provide OEM and ODM service. The 36V/72V/96V model also can be customized for you.


Products Package

Number	quantity	Items included
1	1 pc	Controller color (blue or green is optional OEM ODM order is highly welcome)
2	2 pc	Hangers (used for controller hanging on the wall)
3	4 set	Screw
4	1 pc	RJ45 to RS232 cable
5	1 pc	Battery temperature sensor wire
6	2 pc	Fuse[DC output[]
7	1 pc	User instruction[manual[
8	1 pc	CD

Controller PC upper software and testing software

1.Controller PC upper software and testing software can display information. Users can set parameters via PC upper software.





Graphical: PC upper software

Graphical: testing software

- 1.1 The first picture show solar controller working status(charge and discharge), PV voltage, charge voltage, charge current etc. Users can choose the type of the batteries, DC-load output control method.1.2 We provide PC upper software. Testing software is not including. (user's PC has software development platform, if needed, please apply for it)
- 2. Information display and parameter setting.





Figure 2.1

Figure 2.2

2.1 ENTER1 button: press left ENTER1 show 2 digital battery voltage ☐ if it is charging, then shows 2 digital charge voltage), for example, the battery voltage or charge voltage is 13.5V, it shows13, please see Figure 2.1; Press ENTER1 a little bit longer, users can set battery types.

2.2 ENTER2 button: press right ENTER2 show 2 digital battery current (if it is not charging, then it display 00, if the charge current is 22.5A, then it shows 22,please see Figure 2.2); press ENTER2 button a little bit longer, DC load control can be set (On mode, Off mode, PV voltage control mode) Please see more details in the user manual.

Other detailed parameters

Please see the outline of the design, technical documents, user manuals etc. Research and development department made 2th version on May 5, 2014.