Feature:

- 1.MPPT charge mode, conversion efficiency upto 99%
- 2.12V/24V/48V system auto recognize
- 3. Wide range of PV input with max. is DC150V.
- 4. Journal function, Save function set, Date, time, Generating capacity and so on.
- 5.Charge mode: three stages (fast charge ,constant charge ,floating charge) .lt prolongs service life of the batteries .
- 6.Discharge mode: ON mode, OFF mode, double time control mode, PV voltage control mode ,PV voltage plus time delay mode and so on .
- 7.Recommended battery types: sealed lead acid, vented, gel, NiCd battery. Other types of the batteries can also be defined.
- 8.Most information could be provide by LCD and LED like: model number, PV input voltage, battery type, battery voltage, charging current, charging power, working status and so on. Also customer information like company name, website and logo can be added into Solar Eagle software.
- 9.RS232 and LAN communication port. IP and Gate address could be user define it satisfy global area.And communication protocol can be provided to help customer manage all information .
- 10. The upper computer software is displayed in 11 languages, it could show work status and set parameters of the discharge system.
- 11. With intelligent design, the device can be upgraded online lifelong.
- 12.Adopting the well-known brand components, the devices can suffer the temperature not less than 105°C. The service life is designed to use for 10 years in theory.
- 13. Compliance with the 2002 95 EC environment protecting demand, does not include the Cadmium, hydride and fluoride etc material
- 14.Equipment integrity: controller ,CD-ROM(microcomputer software), communication wire , temperature sensing wire,Anderson terminals
- 15.CE,ROHS certifications approved.
- 16.2 years warranty. And 3~10 years extended warranty service also can be provided.

Technical Specification:

recillical opeci					
MODEL SMART2-20A/25A/30A - SERIES		20A	25A	30A	
Charge Mode		Maximum Power Point Tracking			
Discharge Mode		Intelligent control			
System Type		12V 24V 48V Automatic recognition			
Soft Start Time		≤10S			
Dynamic Response Recovery Time		500us			
Conversion Efficiency		≥96.5%,≤99%			
PV Modules Utilization Rate		≥99%			
INPUT CHARACTER	ISTICS				
MDDT Working	12V system	DC18V~DC150V			
MPPT Working Voltage and Range	24V system	DC34~DC150V			
	48V system	DC65~DC150V			
Low Voltage Input	12V system	DC16V			
Low Voltage Input Protection Point	24V system	DC30V			
	48V system	DC60V			
Low Voltage Input Recovery Point	12V system	DC22V			
	24V system	DC34V			
	48V system	DC65V			
Max. DC Voltage		DC160V			
Input Overvoltage Protection Point		DC150			
Input Overvoltage Recovery Point		tDC145V			

	12V system	286W	357W	429W	
Max. PV Power	24V system	572W	715W	858W	
	48V system	1144W	1430W	1716W	
CHARGE CHARAC			12 13011	127 2011	
Selectable Battery Types		Sealed lead acid, vented, Gel, NiCd battery(Default type is GEL battery)			
Other types of Battery Setting		Constant charge	User-defined co charge voltage	nstant/floating range between	
		Floating charge	DC10V~DC15 (based on 1 pcs 12V battery)		
Battery Type Setti	Battery Type Setting		Controller and u		
IL NAMO IVNO		12V/24V/48V SYS	charge	ast t charge/Floating	
Rated Output Curi	rent	20A	25A	30A	
Current-limiting P	rotection	25A	30A	35A	
Temperature Fact	or	±0.02%/℃			
Temperature Com	pensation	14.2V-(The high	14.2V-(The highest temperature-25°C)*0.3		
Output Ripples(pe	ak)	200mV			
Output Voltage St	ability Precision	≤±1.5%			
Charge voltage Pe					
Charger voltage a		≤±1.5%			
DISCHARGE CHAR					
Setting Control		Controller or LAN	V		
Max discharge cui	rent	30A			
Max discharge po			840W	1680W	
Discharge protect		fuse 40A*2	0.011	1200011	
Double-time control			off in morning / C	On in night ,off in	
ON / OFF mode		ON / OFF			
PV voltage contro		PV voltage on,PV voltage off			
PV voltage / time		PV voltage on,time delay off			
Discharge voltage protection		Output off when it under setting voltage; Factory set is 10.5 .(Note : set based on 1 battery)			
COMMUNICATION	PORT	·		, , , , , , , , , , , , , , , , , , ,	
RS232 Communic	ation	Chose COM communication			
LAN Communicati	on	Set IP and Gate address for controller and solar eagle ;Then chose TCP communication			
PROTECTIONS					
Input Low Voltage	Protection				
Input Overvoltage					
Input Polarity Reversal Protection		Check the in/output characteristics			
Output Overvoltage Protection					
Output Polarity Reversal					
Protection					
Short-circuit Protection		Recover after eliminating the Short-circuit fault, no problem for long term Short-circuit			
		95°C			
Temperature protection		Above 85°C,decrease the output power, decrease 3A per degree.			
OTHER PARAMETE	RS	<u>.</u>			
Noise		≤40dB			

Thermal methods	Forced air cooling, fan speed rate regulated by temperature, when inner temperature is too low, fan ran slowly or stop; when controller stop working, fan also stop ran.		
Environment Protection	World brand raw materials. Compliance with EU standards. Meet the 2002/95/EC without cadmium hydride, fluoride, peculiar smell and toxic substances. All rated temperature of electrolytic capacitors not less than 105°C		
PHYSICAL			
Measurement DxWxH (mm)	270*185*90		
N.G(kg)	2.1		
G.N(kg)	2.4		
Color	Blue/Green (optional)		
Safety	CE, RoHS, PSE,FCC		
EMC	EN61000		
Type of Mechanical Protection	IP21		
ENVIRONMENT			
Humidity	0~90%RH (no condense)		
Altitude	0~3000m		
Operating Temperature	-20°C ~ +40°C		
Storage Temperature	-40°C ~ +75°C		
Atmospheric Pressure	70~106kPa		

Note: We provide OEM and ODM service. The 36V/72V/96V model also can be custom made for you.

Product Parts:



NO.	Quantity	Description	
1	1 pc	Charge controller	
2	2 pc	Gallow pulley (For install the controller on the wall)	
3	4 set	Screw (For install the controller on the wall)	
4	1 pc	232 turn to RJ45 communication cable	
5	1 pc	User manual	
6	1 pc	Temperature sensing wire	
7	2 pc	Fuse wire	

Upper Computer Software and testing Software:







The interface of upper computer software working state

The interface of upper computer software parameter setting state







The interface of test software working state

Note:

- 1) Attachment is upper computer software which is suitable for all computer systems .
- 2) Trafficker will provide neutral upper computer software and CD, or with customer's logo.
- 3) WIN7,IN8 system user,please log in as administrator. More details please check the manual.

Information on Display and Settable Parameters:



Note:

- 1) All above information is a sample which is the working state of MPPT in sometime. In different working stage the parameters will change like work mode, charge current ,charge mode ,charge power and so on ; In the fault mode it will show fault mode ;
- 2) If all above dates show means this could change; the details please check the manual.

Installation



Note:

- 1) Above is off-grid solar system connection picture;
- 2)Other ways for PC-communication, please check the manul for details;

Other Parameters:

Please check design brief, technical documents, product manual for more details.